

ESW 7020

29 cm high handleless Gourmet warming drawer for preheating crockery, keeping food warm and low temperature cooking.



- The ultimate in enjoyment low temperature cooking
- Always at the right temperature 4 functions
- Convenient and easy Touch control
- Opening the drawer couldn't be easier Push2open
- Better safe than sorry timer function with automatic switch-off

EAN: 4002516169475 / Material number: 11093300 / Old Material Number: 30702030GB

Construction type and design	
Gourmet warming drawer	•
VitroLine	
ArtLine	
Handleless	•
Colour	Graphite grey
Operating modes	
Cup warming	•
Plate warming	•
Keeping food warm	•
Low temperature cooking	•
User convenience	
Miele@home	•
Capacity	12 place settings
Push2open mechanism	•
Fully telescopic runners for easy loading and unloading of the warming drawer	•
Control panel with sensor controls	•
Control panel with symbols	•
Stop programming	•
Timer function	•
Sabbath programme	
Efficiency and sustainability	•
*	0.5
Power rating in off mode in W	
Power rating in standby mode in W	1.0
Power rating in networked standby in W	2.0
Time until automatic switch to off mode in min	20
Time until automatic switch to standby in min	20
Time until automatic switch to networked standby in min	20
Cleaning convenience	
Flush control panel	•
Safety	
Cool front	
Anti-slip mat	
Safety switch-off	•
Technical data	
Temperatures min. in °C	40
Temperatures max. in °C	85
Appliance width in mm	595
Appliance height in mm	289
Appliance depth in mm	570
Useable interior height in mm	230
Total rated load in kW	0.70
Voltage in V	230
Frequency in Hz	50-60
Fuse rating in A	10
Number of phases	1
Mains cable with plug	•
Length of supply lead in m	2.0



ESW 7020

29 cm high handleless Gourmet warming drawer for preheating crockery, keeping food warm and low temperature cooking.




EAN: 4002516169475 / Material number: 11093300 / Old Material Number: 30702030GB

Accessories supplied	
Anti-slip mat	1
Rack for increased capacity	1


Míele

ESW 7020


29 cm high handleless Gourmet warming drawer for preheating crockery, keeping food warm and low temperature cooking.



ESW7x20, DGC7x4xHCPro, DGC7x4xHCXPro installation drawings




ESW7x20, DG7xxx, DGM7xxx installation drawings




ESW7x20, DGM7x4x installation drawings


1) Front view, 2) Mains connection cable, L=2.000 mm, 3) Ventilation cut min. 180 cm², 4) No connection in this area



ESW7x20, DGC7x6xHCPro, DGC7x6xHCXPro installation drawings



ESW7020, ESW7120 - installation drawing - GB, AU



ESW7020, ESW7120 - installation drawing – Installation – GB, AU

1) Front view, 2) Mains connection cable, L=2,000 mm, 3) ventilation cut-out min. 180 cm 2 , 4) no connection in this area