



CHILL OUT

DESIGN BY COEN MUNSTERS


10310 / 10311 H6




10322 / 10323 H8




10316 / 10317 H6




10328 / 10329 H12




10334 / 10335 H10




10340 / 10341 H14



10380 C5



10360 W1



CHILL OUT H6 BASE: 6 X G9 / 220V / MAX. 40W

10310 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16
10311 WITH 10 SWAROVSKI® STRASS® BALLS COLOURS 00 01 02 05 10 12 16

CHILL OUT H8 BASE: 8 X G9 / 220V / MAX. 40W

10322 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16
10323 WITH 10 SWAROVSKI® STRASS® BALLS COLOURS 00 01 02 05 10 12 16

CHILL OUT H6 BASE: 6 X G9 / 220V / MAX. 40W

10316 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16
10317 WITH 10 SWAROVSKI® STRASS® BALLS COLOURS 00 01 02 05 10 12 16

CHILL OUT H12 BASE: 12 X G9 / 220V / MAX. 40W

10328 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16
10329 WITH 10 SWAROVSKI® STRASS® BALLS COLOURS 00 01 02 05 10 12 16

CHILL OUT H10 BASE: 10 X G9 / 220V / MAX. 40W

10334 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16
10335 WITH 10 SWAROVSKI® STRASS® BALLS COLOURS 00 01 02 05 10 12 16

CHILL OUT H14 BASE: 14 X G9 / 220V / MAX. 40W








10340 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16
10341 WITH 10 SWAROVSKI® STRASS® BALLS COLOURS 00 01 02 05 10 12 16

CHILL OUT C5 BASE: 5 X G9 / 220V / MAX. 40W

10380 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16

CHILL OUT W1 BASE: 1 X G9 / 220V / MAX. 40W

10360 WITHOUT CRYSTAL COLOURS 00 01 02 05 10 12 16

COLOURS		
		00 BRILLIANT BRASS
		01 SATIN BRASS
		02 CHROME
		05 BRONZE
		10 BLACK MATT
		12 BLACK GLOSSY
		16 MATT NICKEL